

TOPAKUSTIK

Cleaning instructions for TOPAKSTIK and TOPPERFO surfaces of ceilings and walls.

If the surfaces are soiled with dust, clean the grooves and drilling with vacuum cleaner.

Important to observe: use vacuum cleaner mouthpieces only with a soft brush to avoid scratches.

Remove pencil lines with a soft eraser.

Clean the surfaces with lukewarm water containing very mild cleaning agent.

Afterwards, apply with a damp cloth and wipe dry with a dry cloth.

Do not use any scratching towels or brushes or undiluted detergent like nitro thinner, acetone, cleaning sprays, etc.



ACOUSTIC PRODUCTS LIMITED
70C High Street
Whitstable
Kent
CT5 1BB
TEL: 01227 281140
FAX: 01227 281141
enquiries@acoustic-products.co.uk
www.acoustic-products.co.uk

