

TOPAKUSTIK

Cleaning instructions for TOPAKSTIK and TOPPERFO surfaces of ceilings and walls.

If the surfaces are soiled with dust, clean the grooves and drilling with vacuum cleaner.

Important to observe: use vacuum cleaner mouthpieces only with a soft brush to avoid scratches.

Remove pencil lines with a soft eraser.

Clean the surfaces with lukewarm water containing very mild cleaning agent.

Afterwards, apply with a damp cloth and wipe dry with a dry cloth.

Do not use any scratching towels or brushes or undiluted detergent like nitro thinner, acetone, cleaning sprays, etc.



ACOUSTIC PRODUCTS LIMITED
139 TANKERTON ROAD
WHITSTABLE
CT5 2AW
TEL: 01227 281140
FAX: 01227 281141
enquiries@acoustic-products.co.uk
www.acoustic-products.co.uk

