


TOP)A)K)U)S)T)I)K) 

Cleaning instructions for TOPAKUSTIK® and TOPPERFO® surfaces of ceilings and walls

The surfaces soiled with dust, clean the grooves and drillings with vacuum cleaner.

Important to observe: use vacuum cleaner mouthpieces only with a soft brush to avoid scratches.

Remove pencil lines with a soft eraser.

Clean the surfaces with lukewarm water, containing very little and mild cleaning agent.

Afterwards apply with a damp cloth and wipe dry with a dry cloth.

Wash off persistent soilings with diluted soap water, for exemple curd soap.

Afterwards wipe damp with a damp cloth and polish with a soft dry cloth.

Do not use any scratching towels or brushes or undiluted detergent like nitro thinner, acetone, cleaning sprays a.s.o.

TOP)A)K)U)S)T)I)K)® TOP)P)E)R)F)O)®

N'H AKUSTIK + DESIGN AG
OBSEESTRASSE 11
6078 LUNGERN . SCHWEIZ
MWST-NR. 165 406

CONTACT@TOPAKUSTIK.CH
WWW.TOPAKUSTIK.CH
T +41 41 679 73 73
F +41 41 679 73 79

